

# BLACK BUNKER™

# BM8

## SURVIVAL AIR RIFLE

## CARABINE À AIR COMPRIMÉ

**Compact Design: easy to store and carry**

Design compact: facile à ranger et à transporter

**Break barrel gas ram technology**

Technologie: canon basculant/piston à gaz



## BM8 USER MANUAL

Manual English 100632 Ver5.0

BLACK BUNKER



## OWNER'S MANUAL – BREAK BARREL AIR RIFLE.

.177, .22 caliber pellets.

READ ALL INSTRUCTIONS AND WARNINGS BEFORE USING.

BLACK BUNKER  
4230 Lake Avenue  
Fort Wayne  
IN 46815, USA  
[www.black-bunker.com](http://www.black-bunker.com)

If you have questions, contact BLACK BUNKER at 1-800-533-4831 or [www.black-bunker.com](http://www.black-bunker.com).

REMEMBER, THIS AIR RIFLE IS NOT A TOY. ALWAYS TREAT THE AIR RIFLE AS THOUGH IT IS LOADED AND WITH THE SAME RESPECT YOU WOULD A FIREARM.

**⚠ WARNING:** NOT A TOY. THIS AIR RIFLE IS RECOMMENDED FOR ADULT USE ONLY. MISUSE OR CARELESS USE MAY RESULT IN SERIOUS INJURY OR DEATH. DANGEROUS WITHIN 750 YARDS (688 METERS).

DEPENDING ON YOUR MODEL, YOUR BM8 AIR RIFLE WILL SHOOT .177 OR .22 CALIBER PELLETS REFER TO MARKINGS ON THE BM8 AIR RIFLE FOR THE CORRECT CALIBER PELLET SIZE FOR YOUR PARTICULAR AIR RIFLE MODEL. YOU AND OTHER WITH YOU SHOULD ALWAYS WEAR SHOOTING GLASSES TO PROTECT YOUR EYES. BUYER AND USER HAVE A DUTY TO OBEY ALL LAWS REGARDING THE USE & OWNERSHIP OF THIS AIR RIFLE.

**⚠ WARNING:** DO NOT BRANDISH OR DISPLAY THIS AIR RIFLE IN PUBLIC – IT MAY CONFUSE PEOPLE AND MAY BE A CRIME. POLICE AND OTHERS MAY THINK IT IS A FIREARM. DO NOT CHANGE THE COLORATION AND MARKINGS TO MAKE IT LOOK MORE LIKE A FIREARM. THAT IS DANGEROUS AND MAY BE A CRIME.

**⚠ WARNING:** PROPOSITION 64: THIS PRODUCT CONTAINS ONE OR MORE CHEMICALS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER & BIRTH DEFECTS (OR OTHER REPRODUCTIVE HARM).


**CAUTION:** This air rifle has been classified as an adult air rifle. Adult air rifles are exempt from performance requirements for trigger mechanisms. Safety mechanisms and drop tests. NOTICE: There may be a 250-shot break in period with break barrel air rifles. During this period accuracy may be inconsistent and you air rifle may appear loud. This will improve as the air rifle breaks in.

### 1. IMPORTANT SAFETY INFORMATION

- **ALWAYS** treat the air rifle as though it is loaded and ready to fire.
- **ALWAYS** treat air rifles with the same respect you would a firearm.
- **ALWAYS** store the air rifle away from children.
- **ALWAYS** aim in a SAFE DIRECTION.
- **ALWAYS** keep the muzzle of the air rifle pointed in a SAFE DIRECTION.
- **ALWAYS** keep your finger off the trigger and out of the trigger guard until ready to shoot.
- **ALWAYS** keep the air rifle "ON SAFE" until you are ready to shoot (**Fig. 3A**).
- **ALWAYS** check to see if the air rifle is "ON SAFE" (**Fig. 3A**) and unloaded when removing or placing it in storage.
- **ALWAYS** check to see if the air rifle is "ON SAFE" (**Fig. 3A**) and unloaded when handing it to or receiving it from another person.
- **ALWAYS** have you and others wear shooting glasses to protect your eyes.
- **ALWAYS** wear shooting glasses over eyeglasses or prescription glasses.
- **ALWAYS** place a shooting backstop in a location that will be safe should the backstop fail.
- **ALWAYS** check your backstop for wear before and after each use. All backstops are subject to wear and will eventually fail. Replace your backstop if the surface is worn or damaged, or if a ricochet occurs.
- **ALWAYS** use the proper size pellet in your air rifle. Check the markings on your air rifle to verify the pellet size.
- **NEVER** store your air rifle with loaded ammunition.
- **NEVER** store your air rifle in cocked condition.
- **NEVER** point the air rifle at any person or at anything you do not intend to shoot.

- **NEVER** reuse ammunition.
- **NEVER** shoot at hard surfaces or at the surface of water. The pellet may bounce off or ricochet and hit someone or something you had not intended to hit.
- **NEVER** attempt to disassemble or tamper with your air rifle. Use an Authorized Service Station. Using an unauthorized service or repair center or modifying the function of your air rifle in any way, may be unsafe and will void your warranty.


## 2. LEARN THE PARTS OF YOUR BLACK BUNKER BM8 (FIG 1)



- |                                   |                              |
|-----------------------------------|------------------------------|
| A. Stock.                         | J. Trigger.                  |
| B. Stock release latch.           | K. Trigger guard.            |
| C. Picatinny rail.                | L. Safety lever.             |
| D. Rear sight.                    | M. Cocking link arm release. |
| E. Barrel.                        | N. Fore stock.               |
| F. Front sight.                   | O. Picatinny rail.           |
| G. Muzzle.                        | P. Knife. (optional extra)   |
| H. Folded assembly locking catch. | Q. Knife release latch.      |
| I. Grip.                          |                              |

## 3. PINCH POINTS BLACK BUNKER BM8

- There are several moving parts on your air rifle that without showing due care you could trap your fingers in.
- Always ensure these areas are free from any obstruction.




**⚠ WARNING:** KEEP FINGERS CLEAR OF THE PINCH POINTS SHOWN IN FIG 2.


## 4. OPERATING THE SAFETY BLACK BUNKER BM8

**CAUTION:** Like all mechanical devices, an air rifle safety can fail. Even when the safety is in the “S” (safe) position, you must continue to always handle the air rifle in a safe and responsible manner.

- Locate the safety in front of the trigger. (Fig 3A/3B)
- The letters “S” (Safe) and “F” (Fire) are found on both sides of the BM8 air rifle and always indicates the position of the safety.
- Moving the safety towards the trigger puts the safety on in the “S” (Safe) position and prevents activation of the trigger preventing the rifle been fired (Fig 3A)
- When the air rifle safety is in the forward position “F” (Fire) the trigger can be activated and it is able to be fired (Fig 3B)
- Do not move the safety to the “F” (Fire) position until you have read and fully understood instructions & warnings within this manual.



SAFETY ON “S” (Safe)  
FIG 3A



SAFETY OFF “F” (Fire)  
FIG 3B

## 5. COCKING BLACK BUNKER BM8

### **⚠ WARNING:**

- NEVER PLACE YOUR HAND OR FINGERS OVER THE END OF THE MUZZLE
- NEVER POINT THE MUZZLE TOWARDS YOU OR ANY OTHER PERSON
- DO NOT TOUCH THE TRIGGER OR PUSH THE SAFETY TO "F" (FIRE) POSITION
- DO NOT COCK YOUR AIR RIFLE UNTIL YOU ARE READY TO LOAD & FIRE, SINCE THE ONLY WAY TO UNCOCK YOUR AIR RIFLE IS TO FIRE IT,

### CAUTION:

- Never allow the barrel to spring back before the action is engaged.
- Do not pull the trigger until the barrel is returned to the firing position.
- Do not fire your rifle without a pellet in the chamber.
- Dry firing may cause damage to your air rifle.



**FIG 4A**



**FIG 4B**

- Put the air rifle safety in the "S" (Safe) position (**Fig. 3A**).
- And additional safety feature is present that safety lever will move automatically to the "S" (Safe) position when the rifle is fully cocked.
- Point the air rifle in a SAFE DIRECTION.
- Hold the rifle close to your body by placing the stock of the rifle on your upper thigh.
- With the palm of your hand, sharply tap the muzzle end of the barrel (**Fig. 4A**) to expose the breech.
- With the rifle resting on your upper thigh, grasp the muzzle end of the barrel.
- Quickly and firmly, pull the muzzle end of the barrel down as far it will go to engage the action (**Fig. 4B**).
- Be careful not to pinch your hand or fingers in the hinge area of the air rifle (**Fig. 2**).


## 6. LOADING BLACK BUNKER BM8

### **⚠ WARNING:**


- NEVER PLACE YOUR HAND OR FINGERS OVER THE END OF THE MUZZLE
- NEVER POINT THE MUZZLE TOWARDS YOU OR ANY OTHER PERSON
- DO NOT TOUCH THE TRIGGER OR PUSH THE SAFETY TO "F" (FIRE) POSITION
- DO NOT COCK YOUR AIR RIFLE UNTIL YOU ARE READY TO LOAD & FIRE, SINCE THE ONLY WAY TO UNCOCK YOUR AIR RIFLE IS TO FIRE IT,

### CAUTION:

- ALWAYS use the proper size pellet in your air rifle. Refer to markings on your air rifle to verify the correct pellet size.
- NEVER reuse pellets.
- The air rifle is designed to work with quality pellets. Use of any other low-quality pellets may cause injury to yourself, others, or damage to the air rifle.



**FIG 5**




**FIG 6**

- With the air rifle in the cocked position, place one pellet, nose forward into the breech (**Fig 5**)
- Ensure that the skirt of the pellet is flush with the face of the breech.
- Move the barrel back to its original position by pushing it up until it locks (**Fig 6**)
- Ensure the barrel is locked in its closed position after loading & cocking to ensure safe operation.
- The air rifle is now loaded and ready to fire, Keep the air rifle on “S” on safe and pointed in a SAFE DIRECTION until you are ready to shoot.

## 7. SIGHTS ADJUSTMENT BLACK BUNKER BM8

- Elevation is set by means of the rear sight-elevating screw situated on the rear- sight base. Turn the dial counterclockwise to make the pellet hit higher on the target and turn the dial clockwise to make the pellet hit lower on the target.
- Windage is set by turning the windage screw located on the right side of the sight. Turn the dial counterclockwise to make the pellet hit to the left on the target and turn the dial clockwise to make the pellet hit to the right on the target.
- Correctly viewing the open sights ensures you are aiming correctly; you should obtain the view as shown in (**Fig 7**)




**FIG 7**

## 8. SCOPE MOUNTING BLACK BUNKER BM8

- The BM8 air rifle is built with an integrated picatinny rail system. The BM8 air rifle has open sights fitted so it is recommended to use high-mount picatinny rings for scopes.

## 9. GENERAL MAINTENANCE BLACK BUNKER BM8

- Periodically check and tighten all stock fasteners.
- Check and tighten scope mounts (if scope has been mounted)
- Periodically check your air rifle. If anything seems changed, like a shorter or weaker trigger pull, this may mean worn out or broken parts.
- Call customer service for assistance before using your air rifle again.
- Your air rifle will maintain proper function longer if you oil it every 250 shots.
- Apply one drop of Tippmann Marker Oil (available at [tippmann.com](http://tippmann.com)) into the compression chamber (**Fig 8**)
- DO NOT use petroleum distillate-based oil or solvents and DO NOT over-oil as this can cause damage to your rifle.
- If you drop the air rifle, visually inspect for damage before using again.
- If anything seems changed, like a shorter or weaker trigger pull, this may mean broken parts. Call Black Bunker Customer Service for assistance before using you air rifle again.



**FIG 8**

### **⚠ WARNING:**

- DO NOT ATTEMPT TO DISASSEMBLE YOUR AIR RIFLE
- DO NOT MODIFY OR ALTER YOUR AIR RIFLE. ATTEMPTS TO MODIFY IN ANY WAY INCONSISTANT WITH THIS MANUAL MAY MAKE YOUR AIR RIFLE UNSAFE, CAUSE SERIOUS INJURY OR DEATH, AND WILL VOID YOUR WARRANTY.
- USE ONLY OIL DESIGNED FOR AIR RIFLES AND DO NOT OVER OIL. TO DO SO CAN CAUSE POSSIBLE DAMAGE TO THE AIR RIFLE AND INJURY TO THE SHOOTER AND BYSTANDERS.

## 10. BREAK IN PERIOD BLACK BUNKER BM8

- During the first 250 shots with a break barrel, accuracy may be inconsistent, and the rifle may seem loud.
- This will improve as the rifle breaks in after 250 shots.

## 11. MANUALLY UNLOADING / CLEARING A JAMMED PELLET BLACK BUNKER BM8

- a. Take the air rifle "OFF SAFE" and point in a safe direction until you are ready to shoot.
- b. Fire the air rifle at a safe target.
- c. If the pellet still does not fire, put your air rifle "ON SAFE"(Fig. 3A) and follow these steps.
- d. Point the air rifle in a SAFE DIRECTION.
- e. Hold the rifle close to your body by placing the stock of the rifle on your upper thigh.
- f. With the palm of your hand, sharply tap the muzzle end of the barrel (**Fig 4A**) to expose the breech.
- g. look down through the breech to confirm a pellet is jammed.
- h. Insert the tapered end of the cleaning rod (not included) into the barrel.
- i. CAREFULLY and slowly, apply more pressure until you push the pellet out of the muzzle.

### NOTE:

- DO NOT reuse a pellet you have removed.
- DO NOT fire your air rifle without a pellet in the chamber (dry fire). This could permanently damage your air rifle.
- If you are not able to unjam your air rifle by following the "clearing a jammed pellet" procedure, take no further action. An Authorized Service Station will unjam your air rifle.

## 12. PERFORMANCE BLACK BUNKER BM8

- Many factors affect velocity, including brand of projectile, type of projectile, lubrication, barrel condition and temperature. This air rifle was designed to function best with high-end ammunition. Use of other low-end ammunition may cause the rifle to malfunction.

## 13. LIMITED ONE YEAR WARRANTY BLACK BUNKER BM8

- This product is warranted to the retail consumer for one year from date of retail purchase against defects in material and workmanship and is transferable. You should retain the original sales receipt as record of date of purchase. If no receipt, the product is warranted for one year from date of manufacture.

### WHAT IS COVERED:

- a. Replacement parts and labor.
- b. Transportation charges to consumer for repaired product.

### WHAT IS NOT COVERED:

- a. Transportation charges to Authorized Service Station for defective product.
- b. Damages caused by abuse, modification, or failure to perform normal maintenance - see Owner's Manual.
- c. Any other expense.
- d. CONSEQUENTIAL DAMAGES, INCIDENTAL DAMAGES, OR INCIDENTAL EXPENSES INCLUDING DAMAGE TO PROPERTY. SOME LOCAL, STATE OR FEDERAL LAWS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

### IMPLIED WARRANTIES

- a. ANY IMPLIED WARRANTIES INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED IN DURATION TO ONE YEAR FROM DATE OF RETAIL PURCHASE. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.
- b. To the extent any provision of this warranty is prohibited by federal, state or municipal law, which cannot be preempted, it shall not be applicable. This warranty gives you specific legal rights and you may have other rights, which vary, from state to state.



### STOP - BEFORE YOU RETURN THIS PRODUCT TO THE STORE

- a. Save on gas and avoid the trip back to the store. Contact our Customer Service/Technical Support representatives for information and trouble-shooting help. Call 1-800-533-4831 or find answers to frequently asked questions at [www.black-bunker.com](http://www.black-bunker.com).

### WARRANTY CLAIM AND REPAIR SERVICE

- b. If your air rifle needs repair - DO NOT ATTEMPT TO DISASSEMBLE IT! Your air rifle requires special tools and fixtures to repair it. Any disassembly or modification not performed by an Authorized Service Center will void the warranty.
- **U.S. Customers** - Contact Black Bunker Customer Service at 1-800-533-4831 or email us via [Black-bunker.com](mailto:Black-bunker.com). You will be instructed where and how to send your air rifle in for repair under warranty or referred to one of our authorized service centers in your area.
- Include with your product a copy of your receipt and a brief description of the problem. Be sure to indicate your name, mailing address, email address and telephone number. Allow 2-4 weeks for repairs. We recommend you use a method of shipping that provides you with a tracking number and insurance options. Black Bunker is not liable for any damaged, lost or stolen merchandise during shipping.
- **Canadian Customers** - Contact Kore Outdoor Canada at 1-800-533-4831.
- **Outside U.S. Customers** - Please contact your point of purchase dealer/distributor. If you do not know your dealer/distributor, contact our International Dept. for assistance at + 1-800-533-4831 or email us via [www.black-bunker.com](http://www.black-bunker.com).

BLACK BUNKER



Black Bunker is a trademark of Kore Outdoor Inc in Canada and USA.  
User Manual Number M-BB-V5 (English)